

Electrical Requirements for the 7000 Power Tower

PLEASE HAND THIS LEAFLET TO YOUR ELECTRICIAN

Three Phase Supply

Socket Requirement 16 amps per phase TPN&E. Female commando socket

Trip Size 16 amps per phase C Type



Single Phase Supply

Socket Requirement 63 Amp Female Commando socket

Trip Size 50 amp. C Type



Each machine will have a male commando plug fitted with a minimum of 2.5m flex.

If position of female socket requires a longer flex please inform us prior to installation.

Any queries? Please call Helionova on 01603 789 010.